



- MOUNTING INSTRUCTIONS:**
1. PREPARE LOCK STILE PER TEMPLATE NO. 10-935 DRILL CYLINDER MOUNTING HOLES IF REQUIRED.
 2. LOCATE CENTERLINE OF CYLINDER ON EXTERIOR OF DOOR AND DRILL IF REQUIRED.
 3. TRIM TAIL PIECE TO FIT INTO PANIC DRIVE BUSHING ASSEMBLY.
 4. MOUNT CYLINDER AND SECURE WITH MOUNTING SCREWS (SUPPLIED BY LOCK MFG.) IF TRIM IS REQ'D PREPARE PER 10-997 TEMPLATE. FOR INSTALLMENT OF PUSHBAR MORTISE "CYLINDER DOGGING" SEE (DWG. 10-979 RE-KEY/CYL. INSTALLMENT INSTRUCTIONS.)
 6. LOCATE MOUNTING HOLE ON INACTIVE STILE DRILL & TAP 1/4-20 THDS. 40"(1016) FROM BTM. OF DOOR.
 7. PANIC ATTACHMENT
- REMOVE FRONT AND REAR END BASE COVERS BY RELEASING 6-32 x 3/16(5) FLAT HD. SCREWS. SECURE ACTIVE END OF PANIC BY INSTALLING 2 EACH 12-24x3/4(19) FLAT HD.M.S.
- SECURE INACTIVE END WITH SINGLE 1/4-20x1/2(13) ROUND HD. M.S. (PHIL.) WITH SEMS THROUGH INACTIVE BASE PLATE. PROCEED BY RE-INSTALLING BASE COVERS ON EACH END OF PANIC BASE.
8. TO INSTALL STRIKE LOCATE 10-24 TAPS ON ACTIVE STILE (2 PLACES).
 9. MOUNT AND SECURE STRIKE. (REF. DETAIL "S")
 10. CHECK OPERATION OF ALL PARTS INCLUDING CYLINDER IF BEING USED TO ASSURE PROPER OPERATION.

- DOGGING INSTRUCTIONS:**
- TO DOG- DEPRESS BAR,INSERT KEY AND TURN CCW UNTIL IT STOPS,RETURN KEY TO ORIGINAL POSITION THEN REMOVE.
- TO UNDOG- INSERT KEY AND TURN CW UNTIL IT STOPS, RETURN KEY TO ORIGINAL POSITION THEN REMOVE.

FUNCTIONAL CYLINDERS	A	DOOR OPENING	L
ILCO			
LOCKWOOD		36"(914)	33"(838)
YALE		42"(1067)	39"(991)
CORBIN	1/4"	48"(1219)	45"(1143)
SCHLAGE	(6)		
RUSSWIN			
WELCH			
KEIL			
SARGENT	3/8"		
	(10)		

DIMENSIONAL TOLERANCES UNLESS OTHERWISE SPECIFIED		APPROVALS		DATE
DECIMAL DIMENSIONS: XX .010 ±		APPROVED		
DECIMAL DIMENSIONS: XXX .005 ±		CHECKED		
ANGULAR ± ° FRACTIONAL ± 1/64		DRAWN	RM	10/08/01

FILE NO. 10-1023	MATERIAL NONE	SCALE NONE
NEXT ASSY. 1295C-KITS	FINISH NONE	
QTY. USED 1	HEAT TREAT	

INSTALLATION GUIDE		SHEET OR SHEETS 1
1295C RIM DEVICE		DWG. NO.
"S" TYPE STRIKE		REV. B
10-1023		



MODEL 1295C