
INSTALLATION INSTRUCTIONS


CAR121 AND CLR123 CLEAR VISION SPEAK-THRUS






2503 E. Vernon Avenue, Los Angeles, CA 90058-1826 Phone: (800) 421-6144 Ext. 7760 Fax (800) 458-7496 crlaurence.com Email: transaction@crlaurence.com


MODEL IDENTIFICATION



CAR121
Clear Vision Speak-Thru with
1-1/4" (32 mm) Thick Acrylic Radius Top Cover
12" (305 mm) W x 14" (356 mm) H
Level 1 Protection



CLR123
Clear Vision Speak-Thru with
1-1/4" (32 mm) Thick Lexgard Radius Top Cover
12" (305 mm) W x 14" (356 mm) H
Level 3 Protection



CDS4S Stainless Spacer Studs 4 Sets (Radius Top Cover Not Included)


IMPORTANT: READ THIS MANUAL THOROUGHLY BEFORE BEGINNING INSTALLATION.

SPECIFICATIONS

- For use with Plastic Glazing Materials only. Not for use on glass.
- Interior use only. Not for an interior / exterior application.
- Designed for mounting onto 1-1/4" (32 mm) Plastic Glazing only. (Threaded shafts can be cut down for thinner glazing.)

FABRICATION REQUIRED


NOTE: Do not use this drawing as a template. Provided for dimensions only. Polished edge work for cut-out is recommended.




crlaurence.com | usalum.com 2

INSTALLATION

1 Twist Threaded Shaft into Stainless Steel Cap to install. Place Clear Plastic Washer over Threaded Shaft next to Cap. Assemble 4 sets.




(2) Insert Threaded Shafts into holes in window from Customer Side. Hold in place with masking tape.




Threaded Shafts. Push Cover tight

(3) From Clerk Side, place one Clear Plastic Washer, one Stainless Steel Spacer, and another Clear Plastic Washer on each Threaded Shaft.



crlaurence.com | usalum.com

INSTALLATION (CONTINUED)



UE ALUMINUM